

K&N Racing Filter installation instructions

Enderle Birdcatcher

This K&N racing air filter was designed to fit and seal onto the opening of an unmodified Enderle Birdcatcher injection hat.

If the injection hat has already been drilled for mounting a filter, the existing holes and mounting pins will be utilized. Hold the K&N filter as tight as possible up to the injection hat so that the gasket is slightly compressed and have someone drill through the existing holes and through the filter flange.

If no filter is currently mounted on the injection hat, two 1/4" spring-loaded quick release pins (like those sold by McMaster Carr) will need to be purchased locally. Two holes for the quick release pins need to be drilled through the injection hat. Position the holes 1-1/2" up from the throttle stop and 1/2" from the edge of the hat. After both holes are drilled in the injection hat, hold the K&N filter as tight as possible up to the injection hat so that the gasket is slightly compressed and have someone drill through the filter flange.

