



## **THROTTLE CONTROL MODULE**

**PART NUMBER 20-1561**

**SEE KNFILTERS.COM FOR CURRENT APPLICATIONS  
AND CARB STATUS ON EACH PART FOR A SPECIFIC VEHICLE**



**If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.**

**NOTE: FAILURE TO FOLLOW INSTALLATION INSTRUCTIONS AND NOT USING THE PROVIDED HARDWARE MAY DAMAGE THE ENGINE.**

**WARNING: The battery cable MUST be disconnected before any components/electrical connections are disconnected. Failure to follow this step may result in DTC's being set and/or poor operation of this kit.**

1. Turn off the ignition and disconnect the negative battery cable.



2. Release the locking tab and then disconnect the Throttle pedal electrical connection.



3. Connect the K&N® throttle wiring harness to the throttle pedal and connect the factory wiring harness to the K&N® wiring harness.



4. Find a suitable location to mount the sensitivity knob, drill a ¼" id hole, remove the knob and install the rheostat then reinstall the knob.

5. Find a suitable location to mount the K&N® Pedal Module and secure with tie wraps. Route the wiring harnesses to the pedal module and secure to the module. Secure the wiring harnesses with the provided tie wraps.

**NOTE: Be sure the wiring harnesses and module will not be tangled in any pedal assemblies or steering components.**

6. Reconnect the vehicle's negative battery cable. Double check to make sure everything is secure and properly positioned before starting the vehicle.

**NOT LEGAL FOR SALE OR USE ON ANY POLLUTION CONTROLLED MOTOR VEHICLE IN CALIFORNIA OR STATES ADOPTING CALIFORNIA EMISSION PROCEDURES.**

See [knfilters.com](http://knfilters.com) for CARB status on each part for a specific vehicle